


Montážní(y) návod 25.

Assembly instructions 25.

Montageanleitung 25.



NA 800	H-XNA 800 S, H-NA 800 S
NA 1200	H-XNA 1200 S, H-NA 1200 S
NA 1400	H-XNA 1400 S, H-NA 1400 S
NA 1600	H-XNA 1600 S, H-NA 1600 S
NA 1800	H-XNA 1800 S, H-NA 1800 S

HOBIS	HN 1100	HNK 1100, XHN 1100
	HN 1200	HNK 1200, XHN 1200
	HN 1400	HNK 1400, XHN 1400
	HN 1600	HNK 1600, XHN 1600
	HN 1800	HNK 1800, XHN 1800

HNK 1100	1 ks		HNK 1600	1 ks		
	3 ks			HNK 1800	3 ks	
	3 ks			H-NA 1600 S	3 ks	
	1 ks			H-NA 1800 S	1 ks	
H-NA 1200 S	4 ks			6 ks		
H-NA 1400 S	4 ks			6 ks		

